



INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS





Figure 1

EN



Figure 2 — BMV3 / BMV4 / BMV5



Figure 3 — BMV3 / BMV4

Dear customer,

We are pleased that you have decided to purchase an ACV burner. The BMV burner model is a modern generation flame burner. The advantage of this burner construction is the extensive energy saving operation with very low emissions (Sampling test according to EN 267:1999-11 Class 3, German environmental label "Blue Angel" according to RAL-UZ 9, Sampling test according to the Swiss Emissions Regulation LRV).

Every burner is checked in the scope of a thorough final inspection. In addition to the hydraulic and electrical parameters, the appearance of the flame is also inspected.

The warranty period as of the date of purchase (receipt date) is 2 years. Please note that the installation, start up and inspection tasks must be accomplished by a trained technician. The installation and operating instructions that are provided contain important information to this purpose.

We recommend a yearly inspection of the burner by a trained technician to guarantee continuous energy saving and low emission operation.

3

Table of contents

Technical data

1.

	1.1	Burner performance	3
	1.2	Certification	3
	1.3	Operating range	3
	1.4	Fuel	3
	1.5	Electrical data	3
	1.6	Burner dimensions	3
	1.7	Acoustic emissions	3
	1.8	Burner components	3
	2.	Assembly	4
	2.1	Assembly dimensions	4
	2.2	Installing the burner	4
	2.3	Service position	4
	2.4	Change of nozzle	4
_	2.5	Nozzle table	4
	2.6	Combustion chamber - minimum dimensions	4
	2.7	Oil supply	5
	2.8	Oil pipes dimensions	5
	2.9	Flexible oil line connection of the burner	6
	2.10	Electrical connection	6
	2.11	General inspections	6
	2	Initial operating and maintenance	6
	3.1	Adjusting burger	7
	3.1	Chimpey draft	7
	3.2	Combustion air	7
	3.5	Elame monitoring	7
	35	Oil pressure	, 8
	36	Final and safety tests	8
	3.7	Chimney	8
	5.7	chinicy	0
			_
	4.	Basic adjustment table	9
	5	Electric wiring diagram : I 0424	10
	5.	Electric winnig diagram : LOA24	10
	6.	Burner quick service	11
	7	Troublochooting	10
		TRATINESNOATINA	



1. TECHNICAL DATA

1.1. Burner performance

Туре	Oil throughput (kg/h)	Burner output (kW)
BMV3	1.4 - 4.1	16 - 48
BMV4	1.4 - 4.1	16 - 48
BMV 5	3.2 - 4.7	38 - 56

* Specifications for units with a low pressure furnace and an exhaust gas loss of approx. 8%.

1.2. Certification

- DIN EN 267:1999-11: register number: 5G966/11
- Class 3 emission limits (only HL60 E/FLV.2-S)
- German ecolabel "Blue Angel" according to RAL-ZU 9: Contract no. 14415 (only HL60 E/FLV.2-S)

1.3. Operating range

- In the chart, you find allowed combustion chamber pressure as function of the oil flow (see fig. 4).
- The operating ranges have been determined on a testing unit and refer to an altitude of approx. 100 m above sea-level and a room temperature of approx. 20°C. The oil flow that can be achieved in practice depends on the starting resistance of the heater.
- The starting resistance is influenced by the combustion chamber, the flue gas line and the starting load. Exact values can therefore only be determined on each respective system.

1.4. Fuel

- Fuel oil EL according to DIN 51603-1
- Heating oil EL, low sulphur, according to DIN 51603-1
- Fuel oil EL A Bio 10 (bio fuel oil according to DIN SPEC 51603-6, fuel oil EL, low sulphur, with up to 10% of FAME according to the quality requirements of DIN 14214)

1.5. Electrical data

Nominal voltage	230 V ~ 50 Hz
Starting power	ca. 435 W
Operating power	ca. 135 - 235 W
Contact rating of the thermostats and switches,	min. 6A~

1.6. Burner dimensions

Specifications of dimensions in mm (see fig. 5 + 6)		
Packing	l 370 / w 350 / h 485 mm	
Transport weight	14.5 kg	

1.7. Acoustic emissions

The sound pressure level at maximum burner performance is 57 dB(A). The measurements were carried out with an accuracy class 2 measuring device according to IEC 60651 at a (horizontal) distance of 2m.

1.8. Burner components

Item	Make	Ref
Motor	Hanning	O1A095-030
Oil pump	Danfoss	BFP 21 L3
Oil pre-heater	Danfoss	FPHE 5
Ignition unit	Cofi	TRK2-40SHK
Photocell	Danfoss	LDS 057H7097
Automatic oil firing unit	Siemens	LOA 24.171B27







Figure 5



Figure 6





Figure 7



Figure 8



Figure 9

2. ASSEMBLY

2.1. Assembly dimensions

The dimensions of the burner and boiler connection are according to DIN EN 226 (dimensions in mm), see figure 7.

2.2. Installing the burner

- Install sliding flange and seal onto the heat generator using the supplied M8 screws. The mounting screw of the sliding flange must be turned upwards.
- Insert burner with burner pipe into the flange until the burner pipe is flush with the inside of the combustion chamber. Observe special instructions of the heat generator manufacturer, if any.
- Tighten the mounting screw of the flange clamp.

Caution: The flange must be oriented to ensure that the burner is installed with the correct angle (see fig. 6).

Install the recirculation tube. •

2.3. Service position

Loosen the service screw by 1/2 turn using a 4 mm hexagon socket wrench (see fig. 8). Turn the burner to the left and remove it from the burner pipe. Then, place it in the service position (see fig. 9).

2.4. Change of the nozzle

- Loosen screw (2) using a 4 mm hexagon socket wrench • and remove the baffle plate (1) (see fig. 9).
- Select a new nozzle according to the required perfor-• mance range (see table on page 9).
- Remove installed nozzle (3) and screw on the selected nozzle (see fig. 9).
- Check the distance between the baffle plate (1) and the nozzle (3) (see fig. 10).
- Install the baffle plate (1) back in place and tighten the screw (2).

Caution: The baffle plate and nozzle could be hot!

- Control and re-adjust the ignition electrodes if necessary • (see fig. 10).
- Bring the burner in operating position and tighten the service screw.

2.5. Nozzle table

The oil flow rate specified in the nozzle table refers to a viscosity of the preheated heating oil of approx. 2 mm2/s.

Combustion chamber - minimum dimensions 2.6.

According to GN 267, low-emission combustion values can only be reached if the combustion chamber minimum dimensions are complied with.

Combustion chamber - minimum dimensions				
Oil flow rate	Diameter resp. height and width	Depth from the baffle plate		
1.0 - 2.0 kg/h	Ø 225 mm	250 - 350 mm		
2.0 - 6.0 kg/h	Ø 300 mm	350 - 612 mm		





Figure 10



Figure 11



2.7. Oil supply

The construction and installation of the system is to be carried out according to DIN 4755. Local regulations are to be observed. The oil line is to be installed to the burner such that the oil hoses can be connected without any constrain. An oil filter with a quick-close valve is to be installed in the connection on the suction side. A return check valve is to be installed in the return flow line. The burner can be operated in a 1 and 2 pipe system. The burner is delivered for a 2-pipe system as standard. The vacuum in the suction line may not exceed 0.4 bar. With a suction height of more than 3.5 m, an oil circulation pump must be installed. With operation with an oil circulation pump or if the oil tank is located higher than the burner pump, the burner must be operated as a 1-pipe system. If the burner is operated as a 1-pipe system, the return flow R must be closed at the burner pump and screw G must be removed (see fig. 11).

The pressure in the oil line may not exceed 1.5 bar. After complete installation of the oil lines, a leak test must be carried out with a pressure of min. 5 bar according to DIN 4755. The burner may not be connected during the leak test.

2.8.	Oil pipes dimensions (see. fig. 12)
------	-------------------------------------

Nominal thermal output of the boiler (kW)	25	35	45
Internal pipe Ø (mm)	4	4	4
H* (m)	Max. length of the oil piping (m)		
0	30	30	20
1	30	23	15
2	23	16	10

 $^{*}H = max.$ intake height in m (low sulphur fuel oil EL, oil temperature >10 °C, up to 700 m above sea level, 1 filter, 1 check valve, 6x 90° bends).



ΕN

5











Figure 15

en 6

2.9. Flexible oil line connection to the burner

The flexible oil line mounted onto the oil pump can be installed to the left or right side (see fig. 13).

<u>Caution</u>: Remove the plugs from the flexible oil line. When connecting to the oil filter, pay attention to the arrow marking on the connection end of the hoses.

3/8" female connection with coupling.

2.10. Electrical connection

The electrical system is to comply with the relevant CE directives, as well as the requirements of the local power utility company. HS, an all-pole circuit breaker with a min. 3 mm contact gap is to be used as main switch. The connection cable must be wired with a 7-pole Euro-plug (plug component) according to DIN 4791 and in accordance with the wiring diagram. The connection is to be made by plugging together the connection cable with the boiler 7-pole Euro-plug (plug component) and the burner 7-pole Euro-plug (socket component). The burner is delivered with a Euro-plug (socket component) as standard.

<u>Caution</u>: Check the Euro-plug (plug component) for proper wiring.

2.11. General inspections

<u>Caution</u>: Before the initial starting up of the burner, the following inspections are to be carried out:

- Is there mains voltage?
- Is the oil supply correct?
- Have the caps been removed from the oil hoses and are the oil hoses properly connected?
- Is the combustion air supply correct?
- Has the burner been properly installed and are the boiler doors closed?
- Is the boiler filled with water?
- Are the boiler and the exhaust gas duct sealed tight?

3. INITIAL OPERATION AND MAINTENANCE

For initial operation of the burner, all necessary switches and controllers must be switched on. If there is voltage at the burner and oil pre-heater, the green indicator lamp lights up and the heating of the oil pre-heaters begins. The heating up time can last up to 2 minutes. After the target temperature has been reached, the motor starts and the ignition is switched on. After time-out of the preliminary venting time, the solenoid valve opens, the heated oil supply is released, and a flame is formed.

At initial starting up of the burner, if the oil pump does not deliver oil within the safety time, a malfunction shut-off occurs. The burner startup can be repeated by resetting the automatic oil firing unit. Venting of the oil pump and the oil line system must be carried out via the manometer connection of the oil pump (see fig. 15).

Caution: Do not allow the oil pump to operate without oil.

EN



Figure 16



Figure 17



Figure 18

3.1. Adjusting the burner

In order to achieve low-emission combustion values, the burner must be adjusted by measuring the exhaust gas using suitable measuring instruments.

The measuring hole (\emptyset 8 mm) is to be located at a distance of twice the diameter of the exhaust pipe behind the heater and is to be closed after the measurement.

<u>Caution</u>: The heater and exhaust gas ducts must be sealed tight.

3.2. Chimney draft

In order to achieve constant combustion chamber pressure, a draft damper must be installed in the exhaust gas line. The draft damper must be installed to ensure that the vacuum in the combustion chamber is not more than 0.1 mbar during operation. For overpressure boilers, refer to the boiler operating instructions to adjust the chimney draft.

3.3. Combustion air

Each burner has been factory-adjusted with a basic air flow rate, according to the installed nozzle. Depending on the combustion chamber and the nozzle tolerance, the basic factory setting leads to an excess of air and must be re-adjusted in all cases. The required quantity of air is determined from the soot contents and the CO₂ measurement. The final adjustment should be performed using the throttle screw.

a. Air flap (see. fig.16)

Turning counter clockwise the air flap set-screw reduces the air flow from the fan. Therefore, the fan pressure measured at the measuring fitting decreases, and the CO₂ content in the exhaust gases increases. Turning the set screw clockwise will open the flap and increase the fan pressure, thus reducing the CO₂ content in the exhaust gases.

b. Baffle plate (see. fig. 16)

- By turning clockwise the baffle plate set-screw, the gap between the burner pipe and baffle plate is reduced, thus reducing the combustion air volume while increasing fan pressure and the CO₂ content of the exhaust gases.
- For reverse direction of rotation, the gap width and thus the combustion air volume increases with decreasing fan pressure thus decreasing the CO₂ content in the exhaust gas.

Pay attention that the fan pressure is kept between 2,0 - 3,5 mbar.

We recommend setting a CO2 content of 12 - 13 vol. %.

Fan pressure measurement is to be carried out at the pressure measurement fitting (1) (see fig. 17).

The soot number may not exceed 0.5 according to the soot number comparison scale.

3.4. Flame monitoring

The photo-current is to be measured in series with the photocell (+pole on terminal 12, max. 5 kOhm inner resistance in the instrument) (see fig. 18).

The photo-current must be between 55 μA and 100 μA at 230 V~ while in operation.

Measuring adapter MA 2 (see fig. 18) available on request.







Figure 19

3.5. Oil pressure

We recommend setting the oil pressure between 9 - 14 bar, see table on page 9 (see fig. 19).

3.6. Final and safety tests

After completion of the exhaust gas measurements, the system must be tested for proper and safe operation of the controller and damper as well as of the automatic oil firing system including safety time.

3.7. Chimney

The correct chimney cross-section provides the necessary delivery pressure for proper functioning of the firing system and discharge of the exhaust gases. For the function-related chimney dimensions, the following original values must at least be known:

- Design and rated heat output of the heater
- Exhaust gas flow of the heater
- Exhaust gas temperature at the outlet of the heater
- CO₂ content of the exhaust gas
- Required delivery pressure for supply air, heater and connection piece
- Design and length of the connection piece
- Design of the chimney and effective chimney height The design and version of the chimney are to be determined according to DIN 4705 and DIN 18160.



Figure 20



4. BASIC ADJUSTMENT TABLE

Burner model	Burner Output	Oil mass flow	Oil nozzle		Oil pressure	Fan pressure	Air flap scale [A] fig. 16	Baffle plate scale [B] fig. 16
	kW	kg/h	Usgal/h	\checkmark	bar	mbar	%	mm
BMV3	25	2.11	0.60	60°H	10.0	2.5	30	6
BMV4	32	2.70	0.60	60°H	14.5	2.5	32	9
BMV5	43	3.63	1.00	45°H	12.0	2.5	46	10



5. ELECTRIC WIRING DIAGRAM : LOA24



A1	Oil	firina	unit

- BM Burner motor
- F1 Fuse max. 6,3 A
- H1 Failure signal
- H2 Operation signal
- HS Main switch
- LDS Photocell
- **OFV** Oil Pre-heater
- P1 Operating hours counter
- TB Temperature or pressure limiter
- TR Temperature or pressure controller
- TT Ignition unit
- V Magnetic valve
- X1 Europlug (7 poles)

в	Blue
Bk	Black
Br	Brown
G	Grey
v	Violet
W	White
Y/Gr	Yellow / Green



6. BURNER QUICK SERVICE



Figure 22 — Loosening of the service screw



Figure 23 — Service position



Figure 24 — Measurement and setting oil pressure



Figure 25 — Disassembly of the oil filter



Figure 26 — Installation position of the air flap



Figure 27 — Disassembly of the nozzle connection cover



Figure 28 — Plug connection for motor



Figure 29 — Connection plug for photocell



ΕN

11

7. TROUBLESHOOTING

1. Oli fining unit No voltage present Ofteck wiring Error signal tamp is not an No voltage present Ofteck wiring Baler transeruture controller incorrectly adjusted Adjust Error signal tamp an Ofterfinit swatched to mathunction Correct mathunction Infining unit detective Relation Check wiring Information of the second statut Defective relations Relation Defective regentation Relation of the second statut Defective relations Bearing defective Relation of the second statut Relation of the second statut Load noise caused by running motors Motor defective Relation on form Bearing defective Relation on form Relation on form Instrument of the second statut Instrument of the second statut Relation on form Instrument of second statut Instrument of the second statut Relation on form Instrument of second statut Instrument of the second statut Relation second statut Instrument of second statut Instrument of second statut Relation second statut Instrument of second statut Insthe second statut Relation second statut	Diagnostic	Cause	Remedy
Error signal samp is not on Belier tamperature controller incurracity adjusted Oil fring unit selective Dil fore dil pre-heater Check wing Dispense Di	1. Oil firing unit		
Boilt Remporature controling incorrectly adjusted Adjust Error signal lamp on Of fiting unit subthed to mailunction Correct mailunction Dia fing unit delective Replace Check wing Amount of the subthed to mailunction Check wing Check of par-heater Joint of the subthed to mailunction Check of par-heater Check of par-heater Joint of the subthed to mailunction Replace capachor Replace capachor Stiff biaring Replace capachor Replace motor Joint of the subthed the mailunction Replace capachor Stiff biaring Replace motor Replace motor Joint of the subthed the subt	Error signal lamp is not on	No voltage present	Check wiring
Error signal tamp on OI fing unit welched to mallunction Oil fing unit defective Correct mallunction Replace 2. Motor Check wing Check wing 2. Motor Check wing Check wing 2. Motor Defective release thermostat of oil pre-heater Replace oil pre-heater Motor does not start Defective release thermostat of oil pre-heater Replace oil pre-heater Autor does not start Defective release thermostat of oil pre-heater Replace oil pre-heater Autor does not start Defective release thermostat of oil pre-heater Replace oil pre-heater Jagniton Motor defective Replace motor Replace motor Jagniton Intermediate defective Replace ignition cable Replace ignition cable No generation of ignition spark Incorrect position of the ignition defective Replace ignition defective Near in preserve Incorrect position of the ignition defective Replace ignition defective Near in preserve Incorrect position of the ignition defective Replace ignition defective No preserve is preser		Boiler temperature controller incorrectly adjusted	Adjust
Oil ling unit idencive incorrect wining of terminal socket Beplace Check wing of terminal Check of pre-heater 2. Motor Amount Check of pre-heater Replace of pre-heater 2. Motor Beplace apacitor Replace of pre-heater 2. Motor Beplace apacitor Replace of pre-heater 2. Motor Defective repeatior Replace apacitor 2. Motor Beplace apacitor Replace apacitor 2. Motor Beplace apacitor Replace apacitor 2. Motor Replace apacitor Replace apacitor 3. Motor Beplace of premo Replace apacitor 3. Motor Replace of premo Replace of premo 3. Motor Beplace diplation unit Replace ignition unit 1. Motor cable defective Replace ignition unit Replace ignition electrodes 0. If insput of rederive Replace ignition electrodes Replace ignition electrodes 0. If insput of rederive Replace ignition electrodes Replace ignition electrodes 0. If insput of rederive Replace ignition electrodes Replace ignition electrodes 0. If insput of rederive Replace ignition electrodes Replac	Error signal lamp on	Oil firing unit switched to malfunction	Correct malfunction
Incorrect wing of terminal socket Check wing Check wing 2. Motor Defective release hermostit of oll pre-heater Replace all pre-heater Motor does not start Defective release hermostit of oll pre-heater Replace all purp hermosit Still bearing Replace all purp Replace all purp Loud noise caused by running motor Motor defective Replace on itp purp Jump defective Replace all purp Replace on itp purp Jump defective Replace all purp Replace on itp purp Jump defective Replace inplano acli purp Replace inplano acli purp Jump defective Replace inplano acli purp Replace inplano acli purp Jump defective Replace inplano acli purp Replace inplano acli purp Oil fing unit defective Replace inplano acli fing unit Replace inplano acli purp Inconsistent in pressum, loud noise Intellective fing unit actertodes Replace inplano acli purp Torosistent in pressum, loud noise Intellective Replace inplano acli purp Inconsistent in pressum, loud noise Intellective acced acli for Replace inplano acli purp Inconsistent inpressum, loud noise Intellectinterel		Oil firing unit defective	Replace
A. Motor Check of pre-heater 2. Motor Beface not start Beface view capacitor Replace capacitor Stift beganing Replace on other Replace on other Stift beganing Beface motor Replace on other Stift beganing Replace motor Replace motor Bearing detective Replace motor Replace motor 3. Ignition Bearing detective Replace induce 3. Ignition Information detective Replace induce 1. Insulator detective Replace induce Replace induce 1. Insulator detective Replace on thing unit Replace induce 1. Insulator detective Replace induce Replace induce <td></td> <td>Incorrect wiring of terminal socket</td> <td>Check wiring</td>		Incorrect wiring of terminal socket	Check wiring
2. Motor Motor Motor does not start Defactive release thermostat of oil pre-heater Replace oil pre-heater Balaces not start Defactive release thermostat of oil pre-heater Replace oil pre-heater Stift di pump Replace oil pre-heater Replace oil pre-heater Loud noise caused by running motor Motor defactive Replace motor 3. Ignition Replace oil pump Replace ignition orabi 3. Ignition sparks Ignition unit defactive Replace ignition cable Media ignition sparks Ignition unit defactive Replace ignition cable Weak ignition sparks Incorrect position of the ignition electrodes Replace ignition electrodes Motor defactive Replace ignition electrodes Replace ignition electrodes Motor defactive Replace ignition electrodes Replace ignition electrodes Motor defactive Replace ignition electrodes Replace ignition electrodes Incorrect position of the ignition electrodes Replace ignition electrodes Replace ignition electrodes Incorrect position of the ignition to the specifications Check oil supply Check oil supply Oil pump dive defactive Replace c			Check oil pre-heater
Motor does not start Defective release thermostel of all pre-heater Replace and pre-heater Defective capacitor Replace andor Stiff bearing Replace andor Stiff bearing Replace motor Loud noise caused by running motor Motor defective As generation of ignition sparks Ignition unit defective No generation of ignition sparks Ignition unit defective No generation of ignition sparks Ignition unit defective Insulator defective Replace ignition unit Insulator defective Replace ignition unit Insulator defective Replace ignition electrodes Vask ignition sparks Ignition electrodes Persition ignition electrodes Insulator defective Replace ignition electrodes Intervent ignition electrodes Vask ignition spark Incorrect position of the ignition electrodes Persition ignition electrodes Incorrect position of the ignition electrodes Persition ignition electrodes Intervent ignition electrodes Persition ignition electrodes Intervent ignition electrodes Persition electrodes Ignition electrodes Persition electrodes Persition el	2. Motor		
Image: second	Motor does not start	Defective release thermostat of oil pre-heater	Replace oil pre-heater
Stiff bearing Replace motor Stiff of pump Replace motor Loud noise caused by running motor Motor defactive Replace motor Bearing defactive Replace motor Replace motor 3.1 grittion Up upp defactive Replace motor 3.1 grittion Infinito unit defactive Replace grittion cable Infinito unit defactive Replace grittion cable Replace grittion cable Vesk lightion spark Infinito unit defactive Replace grittion eactordes Instant defactive Replace grittion eactordes Replace Instant defactive Replace grittion electrodes Replace Instant defactive Replace on pump Replace Instant defactive<		Defective capacitor	Replace capacitor
Index of the pump Replace inpump Loud noise caused by running moto Motor defective Replace motor Baaring defective Replace on tor OI pump defective Replace inpump 3. Ignition Ignition unit defective Replace input on nali No generation of ignition sparks Ignition unit defective Replace ignition cable OI fining unit defective Replace ignition cable Replace ignition cable OI fining unit defective Replace ignition cable Replace ignition cable Veak ignition sparks Incorrect position of the ignition electrodes Position ignition electrodes 4. OI pump Incorrect position of the ignition electrodes Position ignition electrodes 1 for parting oil pump, no oil pressure, loud noise Intake pipe containing air Purge intake pipe 0 il supply not according to the specifications Check oil supply Oil supply not according to the specifications Check oil supply 0 il supply not according to the specifications Check oil supply Oil pump filter 0 il supply not according to the specifications Check oil supply Oil actrop inter other actrop inter othe		Stiff bearing	Replace motor
Loud noise caused by running motor Metor defective Replace motor Oil pump defective Replace in pump Jupition Searing defective Replace ignition unit Ignition cable defective Replace ignition unit Ignition cable Oil pump defective Replace ignition unit Ignition cable defective Oil fining unit defective Replace ignition unit Ignition dectrodes Weak ignition spark Incorrect position of the ignition electrodes Position ignition electrodes Meak ignition spark Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes according to the specifications Check oil supply Oil supply Incorrect position of the ignition electrodes Oil supply not according to the specifications Check oil supply Intake pipe containing air Purge intake pipe Oil supply Oil supply Intake pipe containing air Purge intake pipe Position (He magnetic valve Coupling defective Replace coll pump Position Oil supply for according to the specifications Check oil supply Position Coupling defective <t< td=""><td></td><td>Stiff oil pump</td><td>Replace oil pump</td></t<>		Stiff oil pump	Replace oil pump
Bearing defective Replace oil pump 3. Ignition Ignition up defective Replace oil furm No generation of ignition sparks Ignition unit defective Replace oil furing unit Ignition cable defective Replace oil furing unit Replace oil furing unit Meak ignition sparks Incorrect position of the ignition deletrodes Replace oil furing unit Meak ignition spark Incorrect position deletrodes Replace oil furing unit Meak ignition spark Incorrect position of the ignition deletrodes Replace oil furing unit Meak ignition spark Incorrect position of the ignition deletrodes Replace oil furing unit Incorrect position of the ignition deletrodes Replace oil pump. Replace oil pump. Incorrect position of the ignition deletrodes Replace oil pump. Replace oil pump. Oil spark Ignition according to the specifications Replace oil pump. Intake pipe containing air Purge intake pipe Replace oil pump. Intake pipe containing air Purge intake pipe Replace oil pump. Intake pipe containing air Replace oil pump. Replace oil pump. Intake pipe containing air Replace o	Loud noise caused by running motor	Motor defective	Replace motor
Oil pump defective Replace oil pump 3. Ignition Ignition unit defective Replace ignition cable No generation of ignition sparks Ignition cable defective Replace ignition cable Ignition cable defective Replace ignition electrodes Replace ignition electrodes Inscripted reflective Replace ignition electrodes Replace ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Polec of al supply Incorrect position of the ignition electrodes Check oil supply Interve poe containing air Purege intake pipe <		Bearing defective	Replace motor
3. Ignition No generation of ignition sparks Ignition unit defective Replace ignition cable Ignition cable defective Replace oil firing unit Oil firing unit defective Replace oil firing unit Weak ignition spark Incorrect position electrodes Incorrect position electrodes Position ignition electrodes Ignition cable defective Replace oil signiton electrodes Incorrect position of the ignition electrodes Clean ignition electrodes Incorrect position of the ignition electrodes Clean ignition electrodes Incorrect position of the ignition electrodes Clean ignition electrodes Incorrect position ignition electrodes Clean ignition electrodes Incorrect position ignition electrodes Clean ignition electrodes Ignition operating oil pump, no oil Dil supply not according to the specifications Purge intake pipe Oil supply avalve closed Open stopy avalve Coupling defective Replace coupling Oil pump filter dirty Clean/replace oil pump filter Oil supply avalve closed Coupling defective Replace coil pump Paratin sedimentation (+4 °C) Install at a frost-free place Estrate-fee place Estretrodes Estrate-fee place Replace co		Oil pump defective	Replace oil pump
No generation of ignition sparks Ignition unit defective Replace ignition rable Ignition cable defective Replace ignition rable Weak ignition spark Incorrect position of the ignition electrodes Veak ignition spark Incorrect position of the ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position of the ignition electrodes Otian ignition electrodes Incorrect position ignition electrodes Otian ignition electrodes Otian popi endectore Replace on ignition electrodes Otian popi endectore Replace on ignitin <td>3. Ignition</td> <td></td> <td></td>	3. Ignition		
Index Inplition cable defective Replace oil firing unit Veak ignition spark Incorrect position of the ignition electrodes Position ignition electrodes 4. Oil pump Incorrect position of the ignition electrodes Position ignition electrodes Incorrect position of the ignition electrodes Position ignition electrodes 4. Oil pump Incorrect position of the ignition electrodes Clean ignition electrodes Incorrect position of the ignition electrodes Other of isopply Clean ignition electrodes Incorrect position of the ignition electrodes Clean ignition electrodes Clean ignition electrodes Incorrect position of the ignition electrodes Check oil supply Check oil supply Incorrect position of the ignition electrodes Check oil supply Check oil supply Intake pipe containing air Orgen stop valve Open stop valve Couping defective Replace coli pump Replace coli pump Intake pipe containing air Clean/replace oil pump Replace oil pump Oil pump drive defective Replace coli pump Replace oil pump S. Magnetic valve desent open Coli of the magnetic valve defective Replace oil of the magnetic valve defective<	No generation of ignition sparks	Ignition unit defective	Replace ignition unit
Adjust of a field of the second sec		Ignition cable defective	Replace ignition cable
Insulator defective Replace ignition electrodes Weak ignition spark Incorrect position of the ignition electrodes Position ignition electrodes 4. Oil pump Clean ignition electrodes Clean ignition electrodes Inconsistent oil pressure, loud noise from operating oil pump, no oil pressure is built up Intake pipe leaking (air entry) Check oil supply Inconsistent oil pressure, loud noise from operating oil pump, no oil pressure is built up Intake pipe leaking (air entry) Check oil supply Oil supply not according to the specifications Oheck oil supply Oheck oil supply Oil supply not according to the specifications Oheck oil supply Oheck oil supply Oil supply according to the specifications Oheck oil supply Oheck oil supply Oil supply inter dectrive Replace couling Oheck oil supply Oil pump filter dirty Clean/replace oil pump Pump Paraffin sedimentation (+4 °C) Install at a frost-free place Install at a frost-free place S. Magnetic valve Col oil the magnetic valve defective Replace oil fring unit Proto conductive cell defective S. Hagnetic valve Photo conductive cell defective Replace oil fring unit Replace nozzle		Oil firing unit defective	Replace oil firing unit
Weak ignition spark Incorrect position of the ignition electrodes Obtion ignition electrodes 4. Oil pump Clean ignition electrodes Clean ignition electrodes Inconsistent oil pressure, loud noise from operating oil pump, no oil pressure is built up Intake pipe containing air Check oil supply Oil supply not according to the specifications Check oil supply Check oil supply Pressure is built up Oil supply not according to the specifications Check oil supply Oil supply not according to the specifications Check oil supply Oil supply Oil supply not according to the specifications Check oil supply Oil supply Oil supply not according to the specifications Check oil supply Oil supply Oil supply not according to the specifications Check oil supply Oil supply Oil supply not according to the specifications Porge intake pipe Oil supply Oil pump filter dirty Clean/replace oil pump Porge intake pipe Oil pump drive defective Replace coulping Porge intake pipe Magnetic valve Eval shut-down without flame Eval shut-down without flame Portoonductive cell defective Replace oil fring unit		Insulator defective	Replace ignition electrodes
Ignition electrodes severely contaminated Clean ignition electrodes 4. Oil pump Incansistent oil pressure, loud nois Intake pipe leaking (air entry) Check oil supply form operating oil pump, no oil pressure is built up Intake pipe containing air Purge intake pipe Oil supply not according to the specifications Check oil supply Oil stop valve closed Open stop valve Coupling defective Replace oil pump Oil pump filter dirty Clean/replace oil pump Oil pump drive defective Replace oil pump Parafin sedimentation (+4 °C) Install at a frost-free place Parafin sedimentation (+4 °C) Install at a frost-free place Magnetic valve does not open Coil of the magnetic valve defective Oil fring unit defective Replace coil of the magnetic valve Generation Photo conductive cell defective Replace photocell Fault shut-down without flame Photo conductive cell contaminated Clean photocell generation Photo conductive cell contaminated Clean photocell photocell current >5.5 µA) Replace nozzle Replace nozzle fauth shut-down with flame generation Photo	Weak ignition spark	Incorrect position of the ignition electrodes	Position ignition electrodes
4. Oil pump Inconsistent oil pressure, loud noise from operating oil pump, no oil pressure is built up Intake pipe containing air Oil supply not according to the specifications Check oil supply Intake pipe containing air Oil stop valve closed Open stop valve Check oil supply Oil stop valve closed Open stop valve Coupling defective Replace coupling Oil pump filter dirty Clean/replace oil pump filter Replace oil pump filter Oil pump drive defective Replace oil pump filter Replace oil pump Fault shut-down without flame generation Coil of the magnetic valve defective Replace oil firing unit Fault shut-down with flame generation Photo conductive cell defective Replace photocell Fault shut-down with flame generation Photo conductive cell defective Replace photocell Fault shut-down with flame generation Defective nozzle Replace nozzle Inconsistent atomisation, high CO and soot emissions Defective nozzle Replace nozzle Baffle plate Incorect burner adjustment Adjust oil pressure Baffle plate / burner pipe very contaminated Incorect burner adjustment Adjust oil pressure Fault shut-down with flame generation Incornsistent atomisation of the nozzle Replace nozzl		Ignition electrodes severely contaminated	Clean ignition electrodes
Inconsistent oil pressure, loud noise from operating oil pump, no oil pressure is built upIntake pipe leaking (air entry)Check oil supplyOil supply not according to the specificationsCheck oil supplypressure is built upOil supply not according to the specificationsCheck oil supplypressure is built upOil stop valve closedOpen stop valveCoupling defectiveReplace couplingClean/replace oil pump filterOil pump drive defectiveReplace oil pumpReplace oil pumpOil pump drive defectiveReplace oil pumpReplaceParaffin sedimentation (+4 °C)Install at a forst-free placeFuel oil viscous (-1 °C)Install at a forst-free placeS. Magnetic valve does not openCoil of the magnetic valve defectiveReplace oil firing unit6. Flame monitoringExtraneous light (photocell current >5,5 µA)Remove extraneous lightFault shut-down with flame generationPhoto conductive cell ectetiveReplace photocellPhoto coll current to weak (photocell current < 55 µA)	4. Oil pump		
from operating oil pump, no oil pressure is built up Oil supply not according to the specifications Check oil supply pressure is built up Intake pipe containing air Purge intake pipe Oil stop valve closed Open stop valve Coupling defective Replace coupling Oil pump filter dirty Clean/replace oil pump filter Oil pump drive defective Replace oil pump Parafin sedimentation (+4 °C) Install at a frost-free place Fuel oil viscous (-1 °C) Install at a frost-free place S. Magnetic valve Coil of the magnetic valve defective Magnetic valve does not open Coil of the magnetic valve defective Fault shut-down without flame Extraneous light (photocell current >5,5 µA) Fault shut-down with flame generation Photo conductive cell contaminated Photo conductive cell contaminated Clean photocell Photocell current too weak (photocell current < 55 µA)	Inconsistent oil pressure, loud noise	Intake pipe leaking (air entry)	Check oil supply
Intake pipe containing air Purge intake pipe Oil stop valve closed Open stop valve Coupling defective Replace coupling Oil pump filter dirty Clean/replace oil pump filter Oil pump drive defective Replace oil pump Paraffin sedimentation (+4 °C) Install at a frost-free place Fuel oil viscous (-1 °C) Install at a frost-free place S. Magnetic valve Coil of the magnetic valve defective Magnetic valve does not open Coil of the magnetic valve defective G. Flame monitoring Extraneous light (photocell current >5,5 µA) Fault shut-down without flame Extraneous light (photocell current >5,5 µA) Replace photocell Replace photocell Fault shut-down without flame generation Photo conductive cell defective Photo conductive cell contaminated Clean photocell Photocell current too weak (photocell current <55 µA)	pressure is built up	Oil supply not according to the specifications	Check oil supply
Oil stop valve closedOpen stop valveCoupling defectiveReplace couplingOil pump filter dirtyClean/replace oil pumpOil pump drive defectiveReplace oil pumpParaffin sedimentation (+4 °C)Install at a frost-free placeFuel oil viscous (-1 °C)Install at a frost-free placeS. Magnetic valve does not openCoil of the magnetic valve defectiveOil fring unit defectiveReplace coil of the magnetic valveG. Flame monitoringExtraneous light (photocell current >5,5 μA)Fault shut-down without flame generationExtraneous light (photocell current >5,5 μA)Fault shut-down with flame generation (Photo conductive cell defectiveReplace photocellFault shut-down with flame generation (Photocell current too weak (photocell current < 55 μA)		Intake pipe containing air	Purge intake pipe
Coupling defectiveReplace couplingOil pump filter dirtyClean/replace oil pump filterOil pump drive defectiveReplace oil pumpParaffin sedimentation (+4 °C)Install at a frost-free placeFuel oil viscous (-1 °C)Install at a frost-free placeMagnetic valveCoil of the magnetic valve defectiveReplace coil of the magnetic valveOil fring unit defectiveReplace oil firing unit6. Flame monitoringExtraneous light (photocell current >5,5 µA)Remove extraneous lightFault shut-down without flame generationExtraneous light (photocell current >5,5 µA)Remove extraneous lightFault shut-down without flame generationExtraneous light (photocell current >5,5 µA)Remove extraneous lightFault shut-down with flame generation (Photo conductive cell contaminated (Photocell current to weak (photocell current <55 µA)		Oil stop valve closed	Open stop valve
Oil pump filter dirtyClean/replace oil pump filterOil pump drive defectiveReplace oil pumpParaffin sedimentation (+4 °C)Install at a frost-free placeFuel oil viscous (-1 °C)Install at a frost-free placeS. Magnetic valveReplace coil of the magnetic valveMagnetic valve does not openCoil of the magnetic valve defectiveReplace oil firing unit6. Flame monitoringExtraneous light (photocell current >5,5 μA)Remove extraneous lightFault shut-down with flame generationPhoto conductive cell defectiveReplace photocellFault shut-down with flame generationPhoto conductive cell contaminated Photocell current <55 μA)		Coupling defective	Replace coupling
Oil pump drive defectiveReplace oil pumpParaffin sedimentation (+4 °C)Install at a frost-free placeFuel oil viscous (-1 °C)Install at a frost-free placeS. Magnetic valveCoil of the magnetic valve defectiveReplace coil of the magnetic valveMagnetic valve does not openCoil of the magnetic valve defectiveReplace coil of the magnetic valveOil fring unit defectiveReplace coil of the magnetic valveReplace oil firing unitS. Flame monitoringExtraneous light (photocell current >5,5 μA)Remove extraneous lightFault shut-down with flame generationPhoto conductive cell defectiveReplace photocellFault shut-down with flame generationPhoto conductive cell contaminated Photocell current < 55 μA)		Oil pump filter dirty	Clean/replace oil pump filter
Paraftin sedimentation (+4 °C) Install at a frost-free place Fuel oil viscous (-1 °C) Install at a frost-free place Magnetic valve Install at a frost-free place Magnetic valve does not open Coil of the magnetic valve defective Oil firing unit defective Replace coil of the magnetic valve 6. Flame monitoring Extraneous light (photocell current >5,5 µA) Remove extraneous light Fault shut-down without flame generation Extraneous light (photocell current >5,5 µA) Remove extraneous light Fault shut-down with flame generation Photo conductive cell defective Replace photocell Fault shut-down with flame generation Photo conductive cell contaminated Photocell current too weak (photocell current < 55 µA)		Oil pump drive defective	Replace oil pump
Fuel oil viscous (-1 °C) Install at a frost-free place 5. Magnetic valve Fuel oil viscous (-1 °C) Install at a frost-free place Magnetic valve does not open Coil of the magnetic valve defective Oil firing unit defective Replace coil of the magnetic valve 6. Flame monitoring Extraneous light (photocell current >5,5 μA) Remove extraneous light Fault shut-down without flame generation Extraneous light (photocell current >5,5 μA) Remove extraneous light Fault shut-down with flame generation Photo conductive cell defective Replace photocell Fault shut-down with flame generation Photo conductive cell contaminated Photocell current too weak (photocell current < 55 μA)		Paraffin sedimentation (+4 °C)	Install at a frost-free place
S. Magnetic valveMagnetic valve does not openCoil of the magnetic valve defective Oil firing unit defectiveReplace coil of the magnetic valve Replace oil firing unit6. Flame monitoringFault shut-down without flame generationExtraneous light (photocell current >5,5 μA)Remove extraneous light Replace photocellFault shut-down with flame generationPhoto conductive cell defectiveReplace photocellFault shut-down with flame generationPhoto conductive cell contarninated Photocell current too weak (photocell current < 55 μA)		Fuel oil viscous (-1 °C)	Install at a trost-tree place
Magnetic valve does not open Coll of the magnetic valve delective Replace coll of the magnetic valve Oil firing unit defective Replace oil firing unit 6. Flame monitoring Extraneous light (photocell current >5,5 μA) Remove extraneous light Fault shut-down without flame generation Extraneous light (photocell current >5,5 μA) Replace photocell Fault shut-down with flame generation Photo conductive cell defective Replace photocell Fault shut-down with flame generation Photo conductive cell contaminated Photocell current too weak (photocell current < 55 μA)	5. Magnetic valve	Cail of the magnetic value defective	Deploce call of the magnetic value
6. Flame monitoring Replace on mining unit Fault shut-down without flame generation Extraneous light (photocell current >5,5 μA) Remove extraneous light Fault shut-down with flame generation Photo conductive cell defective Replace photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Inconsistent atomisation, high CO Defective nozzle Replace nozzle Adjust oil pressure Inconsistent atomisation of the nozzle Replace oil pre-heater Adjust burner Baffle plate Inconsistent atomisation of the nozzle Replace nozzle Replace nozzle Baffle plate / burner pipe very contaminated <th< td=""><td>Magnetic valve does not open</td><td></td><td>Replace coll of the magnetic valve</td></th<>	Magnetic valve does not open		Replace coll of the magnetic valve
Fault shut-down without flame generationExtraneous light (photocell current >5,5 μA)Remove extraneous light Replace photocellFault shut-down with flame generationPhoto conductive cell defectiveReplace photocellFault shut-down with flame generationPhoto conductive cell contaminated Photocell current too weak (photocell current < 55 μA)	6 Elame monitoring		
radiu state down with but hame Photo conductive cell defective Replace photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Fault shut-down with flame generation Photo conductive cell contaminated Clean photocell Photo conductive cell contaminated Photocell current < 55 μA)	Fault shut-down without flame	Extraneous light (photocell current >5.5 µA)	Remove extraneous light
Fault shut-down with flame generation Photo conductive cell contaminated Photocell current < 55 μA)	generation	Photo conductive cell defective	Replace photocell
Pault shuf-bown with hame generation Photo contraction contraction contraction Order photocol Photocell current too weak (photocell current < 55 μA)	Equit obut down with flame concretion	Photo conductive cell contaminated	
7. Nozzle Replace nozzle Inconsistent atomisation, high CO and soot emissions Defective nozzle Replace nozzle Oil pressure not in compliance with specification Diaphragm valve defective Adjust oil pressure 8. Baffle plate Replace oil pre-heater Baffle plate / burner pipe very contaminated Inconsistent atomisation of the nozzle Adjust burner Replace nozzle Replace nozzle Replace nozzle	r aut sint-down with hame generation	Photocell current too weak (photocell current $< 55 \mu$ A)	Reset burner
Inconsistent atomisation, high CO and soot emissions Defective nozzle Replace nozzle Oil pressure not in compliance with specification Diaphragm valve defective Adjust oil pressure 8. Baffle plate Replace oil pre-heater Baffle plate / burner pipe very contaminated Incorrect burner adjustment Inconsistent atomisation of the nozzle Adjust burner Replace nozzle Replace nozzle Replace nozzle	7. Nozzle	· · · · · · · · · · · · · · · · · · ·	
and soot emissions Oil pressure not in compliance with specification Diaphragm valve defective Adjust oil pressure 8. Baffle plate Replace oil pre-heater Baffle plate / burner pipe very contaminated Incorrect burner adjustment Inconsistent atomisation of the nozzle Adjust burner Replace nozzle Replace oil pre-heater	Inconsistent atomisation, high CO	Defective nozzle	Replace nozzle
Baffle plate Replace oil pre-heater Baffle plate / burner pipe very contaminated Incorrect burner adjustment Adjust burner Inconsistent atomisation of the nozzle Replace nozzle Replace oil pre-heater	and soot emissions	Oil pressure not in compliance with specification	Adjust oil pressure
8. Baffle plate Baffle plate / burner pipe very contaminated Incorrect burner adjustment Adjust burner Inconsistent atomisation of the nozzle Replace nozzle Replace oil pre-heater		Diaphragm valve defective	Replace oil pre-heater
Baffle plate / burner pipe very contaminated Incorrect burner adjustment Adjust burner Inconsistent atomisation of the nozzle Replace nozzle Replace oil pre-heater	8. Baffle plate		
contaminated Inconsistent atomisation of the nozzle Replace nozzle Replace oil pre-heater	Baffle plate / burner pipe verv	Incorrect burner adjustment	Adjust burner
Replace oil pre-heater	contaminated	Inconsistent atomisation of the nozzle	Replace nozzle
			Replace oil pre-heater
Nozzle is dripping Replace oil pre-heater		Nozzle is dripping	Replace oil pre-heater
Incorrect nozzle type (spraying angle, spraying Insert nozzle according to specification		Incorrect nozzle type (spraying angle, spraying	Insert nozzle according to specification
characteristics, installation size)		characteristics, installation size)	
9. Fan	9. Fan		
Fan delivers not enough air Fan wheel contaminated Clean fan wheel	Fan delivers not enough air	Fan wheel contaminated	Clean fan wheel
Fan wheel damaged Replace fan wheel		Fan wheel damaged	Replace fan wheel
Loud noise during fan operation Fan wheel incorrectly positioned Correctly position fan wheel	Loud noise during fan operation	Fan wheel incorrectly positioned	Correctly position fan wheel
Fan wheel damaged Replace fan wheel		Fan wheel damaged	Replace fan wheel
Air flap incorrectly installed Correctly install air flap		Air flap incorrectly installed	Correctly install air flap

